

Procédure

Ouverture des ports pour accès externe aux applications, serveurs, objets connectés

Accéder à l'interface de configuration :

Etape 1 : Se connecter avec votre navigateur web sur l'adresse IP suivante : 192.168.1.1

Etape 2 : Renseigner l'username / password (par défaut user / corio_user)

Etape 3 : Cliquer sur login

Etape 4 : Cliquer sur « Modify Login Password »

Etape 5 : Cliquer sur Edit

Etape 6 : Renseigner les différents champs (login, mot de passe) et cliquer sur Save

Etape 7 : Aller dans l'onglet Internet -> Puis cliquer Forwarding > Aller Dans Port Mapping > Cliquer sur + New Port Mapping

Etape 8 : Remplir les champs en fonction des paramètres nécessaires à votre équipement

Détail des champs :

- Interface (laisser comme tel)
- Protocol (TCP / UDP ou TCP/UDP)
- Remote Host (Si vous souhaitez restreindre l'accès à une adresse IPv4 publique)
- External Start port (Port d'attaque de l'extérieur) si range nécessaire premier port
- External End Port (Port d'attaque de l'extérieur) si range nécessaire dernier port
- Internal Host (Adresse IPv4 interne ex : 192.168.1.10)
- Internal start port (port interne) si range nécessaire premier port
- Internal end port (port interne) si range nécessaire dernier port
- Mapping Name (Nom de la règle)

Cliquer sur Save

Pas à pas

The screenshot shows the web interface of a Huawei Home Gateway LG8245V. The browser address bar shows the URL <https://192.168.1.1> with a red circle containing the number 1. The page header includes the Huawei logo and the text "Home Gateway | LG8245V". A navigation menu contains the following items: Home, Internet, Home Network, Share, Telephony, and Maintain.

A "Notice" dialog box is displayed in the foreground, containing the following text: "You are currently using the default login password. Please change this password to improve the network security." Below the text is a checkbox labeled "Do not prompt again" which is checked. At the bottom of the dialog are two buttons: "Modify Login Password" and "Save".

The "Login" form is visible in the background. It has two input fields: "Username" and "Password". The "Password" field has a red circle with the number 2 next to it. Below the input fields are two links: "How do I find the default login password?" and "Forget password?". At the bottom of the form is a blue "Log in" button with a red circle containing the number 3 next to it.

At the bottom of the page, there is a footer with the following text: "Copyright © Huawei Technologies Co., Ltd. 2012-2017. All rights reserved. Privacy Policy Open Source Software Declaration".

Pas à pas

Account Management

Your username and password are needed when logging in to the web page. Frequently changing the user name and password can help prevent unauthorized users from accessing the page and modifying important parameters.

▼ Modify Login Password

User	<input checked="" type="checkbox"/> Edit
New username:	<input type="text" value="Votre login"/>
Current password:	<input type="text" value="corio_user"/>
New password:	<input type="text" value="Votre mot de passe"/>
Confirm password:	<input type="text" value="Votre mot de passe"/>
<input type="button" value="Cancel"/> <input type="button" value="Save"/>	

Pas à pas

Forwarding

You can set forwarding rules on the LG8245V so that users can easily access server resources provided by your computer (such as personal websites and FTP servers) from the Internet.

▼ Port Mapping

[What's this?](#)

 Edit  Delete

Type: Customization Application

Interface:

Protocol:

Remote host:

External start port:

External end port:

Internal host:

Internal start port:

Internal end port:

Mapping name:

Cancel

Save